CODING TABLE

IAC VOR Z RWY 16R					NATAL / Campo Augusto Severo, MIL (SBNT)							SBNT_IAC_00M		24 DEC 26	
Seq Num	**Transition Identifier**	**Fly Over**	**Rec Navaid**	**Fix Ident**	**Path and Terminator**	**Course Angle**	**Turn**	**Upper Limit Altitude (FT)**	**Lower Limit Altitude (FT)**	**Speed Limit (KT)**	**Speed Limit Description**	**TM DST (NM)**	**VA (º)**	**Role of the Fix**	**Navigation Specification**
10	APCH	N/A	N/A	NTL	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	NTL	NTL	FC	348.35° Mag 328.09° True	N/A	N/A	+1900	200	-	8.00	N/A	OTHER	N/A
30	APCH	N/A	NTL	VAKAN	CF	147.96° Mag 127.70° True	L	N/A	R1830	N/A	N/A	N/A	N/A	FAF	N/A
10	FINAL	N/A	NTL	VAKAN	IF	N/A	N/A	N/A	R1830	N/A	N/A	N/A	N/A	FAF	N/A
20	FINAL	N/A	NTL	NTL23	CF	147.96° Mag 127.70° True	N/A	N/A	R942	N/A	N/A	2.73	-3.00	SDF	N/A
30	FINAL	N/A	NTL	NTL22*	CF	147.98° Mag 127.72° True	N/A	N/A	@211	N/A	N/A	2.27	-3.00	FTP	N/A
10	MA	N/A	NTL	N/A	CA	168.00° Mag 147.74° True	N/A	N/A	+2000	200	-	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	NTL	DF	N/A	R	N/A	+3000	200	-	N/A	N/A	MAHF	N/A
30	MA	N/A	NTL	NTL	HM	10.00° Mag 349.74° True	L	N/A	+3000	200	-	1.00 min	N/A	MAHF	N/A

(*) Fictitious point: only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR/DME NTL	S 05:54:30.00 W 35:14:55.20
VAKAN	S 05:51:12.14 W 35:19:10.85
NTL22	S 05:54:16.73W 35:15:12.35
NTL23	S 05:52:52.91 W 35:17:00.66

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT