


AIRCRAFT PARKING/
DOCKING CHART (PDC)

BOA VISTA / Atlas Brasil Cantanhede, INTL (SBBV)

RR - BRASIL

AD ELEV: 276'

ARP N02 50 29 W060 41 32



COORDENADAS DOS PONTOS DE ESTACIONAMENTO
PARKING SPOT COORDINATES

PONTO SPOT	COORDENADAS COORDINATES	PONTO SPOT	COORDENADAS COORDINATES
PÁTIO 1 / APRON 1			
1	02 50 32.16 N 60 41 31.24 W		
2	02 50 31.26 N 60 41 32.86 W		
2B	02 50 30.93 N 60 41 32.92 W		
3	02 50 30.42 N 60 41 34.62 W		
3A	02 50 30.52 N 60 41 33.73 W		
3B	02 50 30.10 N 60 41 34.54 W		
4	02 50 29.77 N 60 41 35.88 W		
4A	02 50 29.68 N 60 41 35.34 W		
4B	02 50 29.31 N 60 41 36.08 W		
5	02 50 28.91 N 60 41 37.57 W		
6	02 50 29.76 N 60 41 40.05 W		
6B	02 50 29.89 N 60 41 40.71 W		
PONTO SPOT	COORDENADAS INS INS COORDINATES		
1	02 50 29.54 N 60 41 35.62 W		
2	02 50 31.44 N 60 41 39.21 W		

CHANGES: LAYOUT: WDI