



CODING TABLE

SID RNAV SOFIA 1A RWY 17					BAURU / Bauru - Arealva (SBAE)							SBAE_SID_00D		11 JUN 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role Of TheFix	Navigation Specification
10	RWY	Y	N/A	AE022	CF	174.94° Mag 153.91° True	N/A	N/A	N/A	N/A	N/A	3.00	N/A	OTHER	RNAV 1 or RNP 1
20	RWY	N	N/A	SOFIA	TF	244.86° Mag 223.99° True	R	N/A	N/A	N/A	N/A	20.00	N/A	OTHER	RNAV 1 or RNP 1
10	NEVKU	N/A	N/A	SOFIA	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	NEVKU	N	N/A	NEVKU	TF	316.65° Mag 296.08° True	R	N/A	N/A	N/A	N/A	48.62	N/A	OTHER	RNAV 1 or RNP 1
10	MANVA	N/A	N/A	SOFIA	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	MANVA	N	N/A	MANVA	TF	301.42° Mag 280.93° True	R	N/A	N/A	N/A	N/A	49.78	N/A	OTHER	RNAV 1 or RNP 1
10	DEXOV	N/A	N/A	SOFIA	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	DEXOV	N	N/A	DEXOV	TF	262.49° Mag 241.93° True	R	N/A	N/A	N/A	N/A	34.04	N/A	OTHER	RNAV 1 or RNP 1
10	ESAVA	N/A	N/A	SOFIA	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	ESAVA	N	N/A	ESAVA	TF	187.14° Mag 166.31° True	L	N/A	N/A	N/A	N/A	30.39	N/A	OTHER	RNAV 1 or RNP 1

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
17	S 22:10:07.99 W 49:03:57.78	1961.00

IDENT	Latitude / Longitude (WGS84) DD:MM:SS.SS
AE022	S 22:12:50.40W 49:02:32.40
SOFIA	S 22:27:17.40W 49:17:30.60
NEVKU	S 22:05:57.38W 50:04:39.55
MANVA	S 22:17:57.84W 50:10:16.31
DEXOV	S 22:43:25.10W 49:49:56.01
ESAVA	S 22:56:54.23W 49:09:44.73

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE