



CODING TABLE

SID RNAV DOGPI 3A RWY 06L					ANÁPOLIS / Campo Marechal Márcio de Souza e Mello, MIL (SBAN)							SBAN_SID_00B		16 APR 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	Y	N/A	DOGPI	CF	60.68° Mag 39.09° True	N/A	N/A	N/A	N/A	N/A	3.00	N/A	OTHER	RNAV 1 or RNP 1
10	TIPTU	N/A	N/A	DOGPI	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	TIPTU	N	N/A	TIPTU	TF	100.96° Mag 79.27° True	N/A	N/A	N/A	N/A	N/A	15.31	N/A	OTHER	RNAV 1 or RNP 1
10	GNV	N/A	N/A	DOGPI	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	GNV	N	N/A	AN017	DF	N/A	L	N/A	N/A	250	-	N/A	N/A	OTHER	RNAV 1 or RNP 1
30	GNV	N	N/A	GNV	TF	209.71° Mag 188.24° True	N/A	N/A	N/A	N/A	N/A	26.92	N/A	OTHER	RNAV 1 or RNP 1
10	EGBOP	N/A	N/A	DOGPI	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	EGBOP	N	N/A	EGBOP	TF	20.71° Mag 359.30° True	N/A	N/A	N/A	N/A	N/A	22.75	N/A	OTHER	RNAV 1 or RNP 1
10	XIXIT	N/A	N/A	DOGPI	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	XIXIT	N	N/A	XIXIT	TF	346.17° Mag 324.66° True	N/A	N/A	N/A	N/A	N/A	22.53	N/A	OTHER	RNAV 1 or RNP 1
10	KOPKO	N/A	N/A	DOGPI	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	KOPKO	N	N/A	AN017	DF	N/A	L	N/A	N/A	250	-	N/A	N/A	OTHER	RNAV 1 or RNP 1
30	KOPKO	N	N/A	KOPKO	TF	292.12° Mag 270.73° True	N/A	N/A	N/A	N/A	N/A	17.78	N/A	OTHER	RNAV 1 or RNP 1
10	KOXUM	N/A	N/A	DOGPI	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	KOXUM	N	N/A	AN017	DF	N/A	L	N/A	N/A	250	-	N/A	N/A	OTHER	RNAV 1 or RNP 1
30	KOXUM	N	N/A	KOXUM	TF	272.27° Mag 250.93° True	N/A	N/A	N/A	N/A	N/A	26.72	N/A	OTHER	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR GNV	S 16:38:27.91 W 49:12:40.47
DOGPI	S 16:10:34.83 W 48:55:15.72
TIPTU	S 16:07:43.80 W 48:39:37.80
AN017	S 16:11:41.51 W 49:08:39.24
EGBOP	S 15:47:44.00 W 48:55:33.00
XIXIT	S 15:52:07.53 W 49:08:48.42
KOPKO	S 16:11:28.64 W 49:27:07.70
KOXUM	S 16:20:29.00 W 49:34:54.00

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
06L	S 16:12:55.10 W 48:57:13.69	3656.20