



## CODING TABLE

STAR RNAV UTBID 1A RWY 13					BELO HORIZONTE / Pampulha - Carlos Drummond de Andrade (SBBH)							SBBH_STAR_01E		05 OCT 23	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	VULAD	N/A	N/A	VULAD	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	VULAD	N	N/A	UTBID	TF	120.74° Mag / 98.18° True	N/A	N/A	N/A	N/A	N/A	74.00	N/A	OTHER	RNAV 1 or RNP 1
10	REINA	N/A	N/A	REINA	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	REINA	N	N/A	UTBID	TF	159.74° Mag / 137.03° True	N/A	N/A	N/A	N/A	N/A	73.33	N/A	OTHER	RNAV 1 or RNP 1
10	GEVMI	N/A	N/A	GEVMI	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	GEVMI	N	N/A	EKINU	TF	208.19° Mag / 185.26° True	N/A	N/A	N/A	N/A	N/A	104.15	N/A	OTHER	RNAV 1 or RNP 1
30	GEVMI	N	N/A	UTBID	TF	187.57° Mag / 164.68° True	N/A	N/A	N/A	N/A	N/A	46.18	N/A	OTHER	RNAV 1 or RNP 1
10	RWY	N/A	N/A	UTBID	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	RWY	N	N/A	BH058	TF	157.12° Mag / 134.20° True	N/A	-12000	N/A	N/A	N/A	14.11	N/A	OTHER	RNAV 1 or RNP 1
30	RWY	N	N/A	VASIX	TF	157.15° Mag / 134.19° True	N/A	N/A	@9000	N/A	N/A	8.01	N/A	OTHER	RNAV 1 or RNP 1
40	RWY	N	N/A	BH057	TF	157.08° Mag / 134.09° True	N/A	-8000	N/A	N/A	N/A	3.46	N/A	OTHER	RNAV 1 or RNP 1
50	RWY	N	N/A	BH056	TF	156.98° Mag / 133.98° True	N/A	N/A	@7000	N/A	N/A	3.22	N/A	OTHER	RNAV 1 or RNP 1
60	RWY	N	N/A	PUMAT	TF	157.12° Mag / 134.11° True	N/A	N/A	@7000	210	-	6.57	N/A	IAF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
REINA	S 18:26:16.80W 45:34:16.80
UTBID	S 19:20:00.87W 44:41:25.61
BH058	S 19:29:53.03W 44:30:43.06
VASIX	S 19:35:28.98W 44:24:38.25
BH057	S 19:37:54.08W 44:22:00.13
BH056	S 19:40:08.86W 44:19:32.69
PUMAT	S 19:44:44.40W 44:14:32.40
GEVMI	S 16:51:10.80W 44:44:16.80
EKINU	S 18:35:18.33W 44:54:19.63
VULAD	S 19:09:43.29W 45:58:53.33

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT