



CODING TABLE

STAR RNAV EROPO 1A RWY 11L/11R					BRASÍLIA / Pres. Juscelino Kubitschek, INTL (SBBR)							SBBR_STAR_01D	29 OCT 26		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	OPNAX	N/A	N/A	OPNAX	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
20	OPNAX	N	N/A	EROPO	TF	178.80° Mag 157.04° True	N/A	N/A	N/A	N/A	N/A	78.87	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
10	ELISA	N/A	N/A	ELISA	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
20	ELISA	N	N/A	DOSVI	TF	132.00° Mag 110.50° True	N/A	N/A	N/A	N/A	N/A	19.82	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
30	ELISA	N	N/A	EROPO	TF	132.92° Mag 111.16° True	N/A	N/A	N/A	N/A	N/A	35.80	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
10	PADIL	N/A	N/A	PADIL	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
20	PADIL	N	N/A	TOLAT	TF	209.73° Mag 187.81° True	N/A	N/A	N/A	N/A	N/A	104.02	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
30	PADIL	N	N/A	EROPO	TF	209.28° Mag 187.34° True	N/A	N/A	N/A	N/A	N/A	51.76	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
10	TOLAT	N/A	N/A	TOLAT	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
20	TOLAT	N	N/A	EROPO	TF	209.28° Mag 187.34° True	N/A	N/A	N/A	N/A	N/A	51.76	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
10	RWY	N/A	N/A	EROPO	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
20	RWY	N	N/A	BR156	TF	175.21° Mag 153.28° True	N/A	-10000	N/A	N/A	N/A	38.00	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
30	RWY	N	N/A	KOGNO	TF	175.53° Mag 153.51° True	N/A	N/A	+7000	190	-	13.08	N/A	IAF	RNAV 1 <i>or</i> RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
OPNAX	S 13:48:34.02W 49:09:13.97
EROPO	S 15:01:28.00W 48:37:27.00
BR156	S 15:35:32.32W 48:19:44.86
KOGNO	S 15:47:17.80W 48:13:41.66
ELISA	S 14:41:34.57W 49:31:06.53
DOSVI	S 14:48:32.06W 49:11:56.76
PADIL	S 12:26:24.88W 48:16:03.49
TOLAT	S 14:09:54.56W 48:30:37.29

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT