



CODING TABLE

IAC NDB RWY 14					BAURU / Bauru (SBBU)							SBBU_IAC_00E		11 JUN 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	BRU	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	BRU	BRU	HF	142.52° Mag 121.87° True	R	N/A	+4000	N/A	N/A	1.00 min	N/A	OTHER	N/A
10	FINAL	N/A	N/A	BRU	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	OTHER	N/A
20	FINAL	N/A	N/A	BRU	FC	322.52° Mag 201.87° True	N/A	N/A	R3100	N/A	N/A	1.00 min	N/A	OTHER	N/A
30	FINAL	N/A	BRU	BRU01*	CF	142.52° Mag 121.87° True	R	N/A	@2060	N/A	N/A	N/A	N/A	FTP	N/A
10	MA	N/A	BRU	N/A	CA	142.51° Mag 121.85° True	N/A	N/A	+3500	N/A	N/A	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	BRU	DF	N/A	R	N/A	+4000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	N/A	BRU	HM	142.52° Mag 121.87° True	R	N/A	+4000	N/A	N/A	1.00 min	N/A	MAHF	N/A

*Fictitious point: Only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NDB BRU	S 22:18:50.40W 49:06:25.80
BRU01	S 22:20:32.17W 49:03:29.76

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT