



## CODING TABLE

IAC VOR X RWY 08					BOA VISTA / Atlas Brasil Cantanhede, INTL (SBBV)							SBBV_IAC_00L		16 APR 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	BVI	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	BVI	BVI	FC	287.83° Mag 271.67° True	N/A	N/A	+1600	N/A	N/A	7.00	N/A	OTHER	N/A
30	APCH	N/A	BVI	ANROP	CF	72.23° Mag 56.06° True	L	N/A	R1570	N/A	N/A	N/A	N/A	FAF	N/A
10	FINAL	N/A	N/A	ANROP	IF	N/A	N/A	N/A	R1570	N/A	N/A	N/A	N/A	FAF	N/A
20	FINAL	N/A	BVI	BVI02*	CF	72.23° Mag 56.06° True	N/A	N/A	+1020	N/A	N/A	1.77	-3.00	SDF	N/A
30	FINAL	N/A	BVI	BVI07*	CF	72.23° Mag 56.06° True	N/A	N/A	@311	N/A	N/A	2.16	-3.00	FTP	N/A
10	MA	N/A	BVI	N/A	CA	72.22° Mag 56.06° True	N/A	N/A	+1500	N/A	N/A	N/A	N/A	OTHER	N/A
20	MA	N/A	BVI	BVI	DF	N/A	L	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	BVI	BVI	HM	287.83° Mag 271.67° True	R	N/A	+3000	N/A	N/A	1.00 min	N/A	MAHF	N/A

\* Fictitious point: only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR/DME BVI	N 02:51:07.57W 60:41:12.81
ANROP	N 02:48:19.26W 60:45:21.56
BVI02	N 02:49:18.87W 60:43:53.47

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT