



## CODING TABLE

IAC NDB Z RWY 10					CABO FRIO / Cabo Frio, INTL (SBCB)							SBCB_IAC_00C		14 MAY 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role Of TheFix	Navigation Specification
10	FINAL	N/A	N/A	BFR	IF	N/A	N/A	N/A	+4100	N/A	N/A	N/A	N/A	IAF	N/A
20	FINAL	N/A	BFR	N/A	PI	284.43° Mag 261.06° True	N/A	N/A	+2500	N/A	N/A	2.66 min	N/A	N/A	N/A
30	FINAL	N/A	BFR	BFR01*	CF	104.43° Mag 81.06° True	R	N/A	@59	N/A	N/A	N/A	N/A	FTP	N/A
10	MA	N/A	BFR	N/A	VA	104.39° Mag 80.93° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	MA	N/A	BFR	BFR	DF	N/A	R	N/A	+4100	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	BFR	BFR	HM	284.42° Mag 261.01° True	L	N/A	+4100	N/A	N/A	1.00 min	N/A	MAHF	N/A

\*Fictitious point: only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NDB BFR	S 22:55:24.00W 42:04:17.40
BFR01	S 22:55:29.96W 42:04:58.07

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT