



CODING TABLE

STAR RNAV KUBLU 1B RWY 34					BELO HORIZONTE / Tancredo Neves, INTL (SBCF)							SBCF_STAR_01O		26 NOV 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	ISNEM	N/A	N/A	ISNEM	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	ISNEM	N	N/A	KUBLU	TF	216.66° Mag 193.45° True	N/A	N/A	N/A	N/A	N/A	41.91	N/A	OTHER	RNAV 1 or RNP 1
10	USVOL	N/A	N/A	USVOL	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	USVOL	N	N/A	ISNEM	TF	219.46° Mag 196.23° True	N/A	N/A	N/A	N/A	N/A	43.41	N/A	OTHER	RNAV 1 or RNP 1
30	USVOL	N	N/A	KUBLU	TF	216.66° Mag 193.45° True	N/A	N/A	N/A	N/A	N/A	41.91	N/A	OTHER	RNAV 1 or RNP 1
10	OPTEB	N/A	N/A	OPTEB	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	OPTEB	N	N/A	KUBLU	TF	242.07° Mag 218.80° True	N/A	N/A	N/A	N/A	N/A	41.09	N/A	OTHER	RNAV 1 or RNP 1
10	RWY	N/A	N/A	KUBLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	RWY	N	N/A	CF141	TF	242.03° Mag 218.85° True	N/A	B19000	B17000	N/A	N/A	20.11	N/A	OTHER	RNAV 1 or RNP 1
30	RWY	N	N/A	CF138	TF	242.00° Mag 218.87° True	N/A	N/A	+15000	N/A	N/A	11.02	N/A	OTHER	RNAV 1 or RNP 1
40	RWY	N	N/A	AKPUV	TF	241.89° Mag 218.78° True	N/A	N/A	N/A	N/A	N/A	7.91	N/A	OTHER	RNAV 1 or RNP 1
50	RWY	N	N/A	CF169	TF	162.03° Mag 138.95° True	N/A	N/A	+10000	N/A	N/A	6.11	N/A	OTHER	RNAV 1 or RNP 1
60	RWY	N	N/A	CF134	TF	161.75° Mag 138.65° True	N/A	N/A	+9000	N/A	N/A	6.13	N/A	OTHER	RNAV 1 or RNP 1
70	RWY	N	N/A	CF199	TF	161.85° Mag 138.74° True	N/A	N/A	+8000	N/A	N/A	3.41	N/A	IAF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
ISNEM	S 18:14:27.59W 43:24:42.95
KUBLU	S 18:55:22.21W 43:34:59.91
CF141	S 19:11:04.91W 43:48:19.42
AKPUV	S 19:25:53.22W 44:00:53.13
CF138	S 19:19:41.70W 43:55:38.38
CF169	S 19:30:30.53W 43:56:38.40
CF134	S 19:35:07.84W 43:52:20.89
CF199	S 19:37:42.00W 43:49:58.16
OPTEB	S 18:23:15.33W 43:07:50.22
USVOL	S 17:32:37.13W 43:11:57.87

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT