



CODING TABLE

SID RNAV TISKU 1A RWY 07					CAMPOS DOS GOYTACAZES / Bartolomeu Lisandro (SBCP)							SBCP_SID_00E		27 NOV 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	Y	N/A	TISKU	CF	70.42° Mag 46.73° True	N/A	N/A	N/A	N/A	N/A	3.00	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
10	MABSI	N/A	N/A	TISKU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
20	MABSI	N	N/A	MABSI	TF	64.29° Mag 40.35° True	N/A	N/A	N/A	N/A	N/A	59.54	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
10	MOLSU	N/A	N/A	TISKU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
20	MOLSU	Y	N/A	CP004	DF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
30	MOLSU	N	N/A	MOLSU	TF	269.20° Mag 245.56° True	N/A	N/A	N/A	N/A	N/A	41.38	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
10	MCA	N/A	N/A	TISKU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
20	MCA	N	N/A	MCA	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
10	RONIP	N/A	N/A	TISKU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
20	RONIP	N	N/A	RONIP	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR/DME MCA	S 22:20:40.01W 41:46:08.40
TISKU	S 21:39:33.25W 41:15:25.99
CP004	S 21:33:17.40W 41:31:48.00
MOLSU	S 21:50:23.40W 42:12:17.40
RONIP	S 22:01:43.19W 41:04:09.01
MABSI	S 20:54:06.00W 40:34:03.00

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
07	S 21:41:37.09 W 41:17:46.69	51.61

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT