



CODING TABLE

SID RNAV PUPRO 1A RWY 25					CAMPOS DOS GOYTACAZES / Bartolomeu Lisandro (SBCP)							SBCP_SID_00P		27 NOV 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	RWY	Y	N/A	PUPRO	CF	250.40° Mag 226.72° True	N/A	N/A	N/A	N/A	N/A	3.00	N/A	OTHER	RNAV 1 or RNP1
10	MABSI	N/A	N/A	PUPRO	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP1
20	MABSI	N	N/A	MABSI	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP1
10	MOLSU	N/A	N/A	PUPRO	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP1
20	MOLSU	N	N/A	CP046	DF	N/A	R	N/A	+7000	N/A	N/A	N/A	2.86	OTHER	RNAV 1 or RNP1
30	MOLSU	N	N/A	MOLSU	TF	287.55° Mag 263.94° True	N/A	N/A	N/A	N/A	N/A	28.33	N/A	OTHER	RNAV 1 or RNP1
10	MCA	N/A	N/A	PUPRO	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP1
20	MCA	N	N/A	MCA	TF	236.59° Mag 212.92° True	N/A	N/A	N/A	N/A	N/A	43.27	N/A	OTHER	RNAV 1 or RNP1
10	RONIP	N/A	N/A	PUPRO	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP1
20	RONIP	N	N/A	RONIP	DF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR/DME MCA	S 22:20:40.01W 41:46:08.40
PUPRO	S 21:44:15.00W 41:20:46.20
MABSI	S 20:54:06.00W 40:34:03.00
CP046	S 21:47:26.54W 41:42:00.16
MOLSU	S 21:50:23.40W 42:12:17.40
RONIP	S 22:01:43.19W 41:04:09.01

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
25	S 21:42:11.50W 41:18:25.80	57.15

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT