



## CODING TABLE

IAC VOR RWY 28					CRUZEIRO DO SUL / Cruzeiro do Sul, INTL (SBCZ)							SBCZ_IAC_00D		14 MAY 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	CZS	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	CZS	CZS	FC	105.13° Mag 97.40° True	N/A	N/A	+2300	210	-	9.0	N/A	OTHER	N/A
30	APCH	N/A	CZS	AKPID	CF	265.14° Mag 257.42° True	L	N/A	R2280	N/A	N/A	N/A	N/A	FAF	N/A
10	FINAL	N/A	N/A	AKPID	IF	N/A	N/A	N/A	R2280	N/A	N/A	N/A	N/A	FAF	N/A
20	FINAL	N/A	CZS	CZ024*	CF	266.24° Mag 258.52° True	N/A	N/A	R1419	N/A	N/A	2.70	-3.00	SDF	N/A
30	FINAL	N/A	CZS	CZ021*	CF	266.24° Mag 258.52° True	N/A	N/A	@686	N/A	N/A	2.30	-3.00	FTP	N/A
10	MA	N/A	N/A	N/A	VA	266.24° Mag 258.52° True	N/A	N/A	+2000	220	-	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	CZS	DF	N/A	R	N/A	+3000	220	-	N/A	N/A	MAHF	N/A
30	MA	N/A	CZS	CZS	HM	105.07° Mag 97.35° True	R	N/A	+3000	N/A	N/A	1.00 min	N/A	MAHF	N/A

(\*) Fictitious point: only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR CZS	S 07:36:24.47W 72:46:24.49
AKPID	S 07:35:13.48W 72:40:34.35
CZ021	S 07:36:13.51W 72:45:30.40
CZ024	S 07:35:45.90W 72:43:14.21

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT