



CODING TABLE

SID RNAV DALIV 1B RWY 28					CRUZEIRO DO SUL / Cruzeiro do Sul, INTL (SBCZ)							SBCZ_SID_00K		14 MAY 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	DALIV	Y	N/A	CZ017	CF	279.60° Mag 271.93° True	N/A	N/A	N/A	N/A	N/A	3.00	N/A	OTHER	RNAV 1 or RNP 1
20	DALIV	N	N/A	CZ023	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
30	DALIV	N	N/A	DALIV	TF	78.52° Mag 70.66° True	N/A	N/A	N/A	N/A	N/A	48.72	N/A	OTHER	RNAV 1 or RNP 1
SID RNAV NEPIN 1B RWY 28					CRUZEIRO DO SUL / Cruzeiro do Sul, INTL (SBCZ)							SBCZ_SID_00K		14 MAY 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	NEPIN	Y	N/A	CZ017	CF	279.60° Mag 271.93° True	N/A	N/A	N/A	N/A	N/A	3.00	N/A	OTHER	RNAV 1 or RNP 1
20	NEPIN	N	N/A	CZ022	DF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
30	NEPIN	N	N/A	NEPIN	TF	114.23° Mag 106.74° True	N/A	N/A	N/A	N/A	N/A	57.13	N/A	OTHER	RNAV 1 or RNP 1
SID RNAV SIGOB 1B RWY 28					CRUZEIRO DO SUL / Cruzeiro do Sul, INTL (SBCZ)							SBCZ_SID_00K		14 MAY 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	SIGOB	Y	N/A	CZ017	CF	279.60° Mag 271.93° True	N/A	N/A	N/A	N/A	N/A	3.00	N/A	OTHER	RNAV 1 or RNP 1
20	SIGOB	N	N/A	SIGOB	TF	216.59° Mag 208.93° True	L	N/A	N/A	N/A	N/A	60.33	N/A	OTHER	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
CZ017	S 07:35:48.60W 72:49:50.40
CZ022	S 07:45:03.44W 72:46:42.51
NEPIN	S 08:02:11.02W 71:51:45.81
SIGOB	S 08:28:16.20W 73:20:18.00
CZ023	S 07:26:34.22W 72:46:27.64
DALIV	S 07:11:07.20W 71:59:56.40

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
28	S 07:35:58.03 W 72:46:49.46	635.00

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT