



CODING TABLE

SID RNAV MUBAV 2B RWY 29					MANAUS / Eduardo Gomes, INTL (SBEG)							SBEG_SID_02M		27 NOV 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	N/A	N/A	N/A	VA	286.87° Mag / 270.12° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	RWY	N	N/A	MUBAV	DF	N/A	R	-7000	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
10	XOLOK	N/A	N/A	MUBAV	IF	N/A	N/A	-7000	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	XOLOK	N	N/A	EG044	TF	99.58° Mag / 82.86° True	N/A	N/A	N/A	N/A	N/A	96.13	N/A	OTHER	RNP 1 or RNAV 1
30	XOLOK	N	N/A	XOLOK	TF	106.56° Mag / 89.08° True	N/A	N/A	N/A	N/A	N/A	125.93	N/A	OTHER	RNP 1 or RNAV 1
10	ITAMI	N/A	N/A	MUBAV	IF	N/A	N/A	-7000	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	ITAMI	N	N/A	ITAMI	TF	29.39° Mag / 12.68° True	N/A	N/A	N/A	N/A	N/A	78.57	N/A	OTHER	RNP 1 or RNAV 1
10	OSARO	N/A	N/A	MUBAV	IF	N/A	N/A	-7000	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	OSARO	N	N/A	OSARO	TF	11.62° Mag / 354.91° True	N/A	N/A	N/A	N/A	N/A	105.89	N/A	OTHER	RNP 1 or RNAV 1

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
29	S 03:02:18.83 W 60:03:42.66	244.20

IDENT	Latitude / Longitude (WGS84) DD:MM:SS.SS
MUBAV	S 02:51:15.20W 60:06:41.12
EG044	S 02:39:11.12W 58:31:22.20
XOLOK	S 02:37:01.80W 56:25:34.20
ITAMI	S 01:34:13.39W 59:49:28.18
OSARO	S 01:05:15.60W 60:16:04.34

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT