



CODING TABLE

SID RNAV PONTE 1A RWY 09					MANAUS / Campo Ponta Pelada, MIL (SBMN)							SBMN_SID_02A		07 AUG 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	N	N/A	MN002	CF	103.68° Mag / 86.89° True	N/A	-4000	N/A	N/A	N/A	12.09	2.29	OTHER	RNAV 1 <i>or</i> RNP 1
20	RWY	N	N/A	PONTE	TF	184.50° Mag / 167.61° True	N/A	N/A	+6500	N/A	N/A	16.01	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
10	ETAXA	N/A	N/A	PONTE	IF	N/A	N/A	N/A	+6500	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
20	ETAXA	N	N/A	ETAXA	TF	170.33° Mag / 153.40° True	N/A	N/A	N/A	N/A	N/A	52.38	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
10	GIKVI	N/A	N/A	PONTE	IF	N/A	N/A	N/A	+6500	N/A	N/A	N/A	N/A	OTHER	RNAV 1 <i>or</i> RNP 1
20	GIKVI	N	N/A	GIKVI	TF	157.03° Mag / 140.10° True	N/A	N/A	N/A	N/A	N/A	90.53	N/A	OTHER	RNAV 1 <i>or</i> RNP 1

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
09	S 03:08:38.13 W 59:58:40.64	250.69

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
MN002	S 03:07:56.73W 59:46:36.21
PONTE	S 03:23:39.73W 59:43:10.05
ETAXA	S 04:10:43.33W 59:19:41.80
GKVI	S 04:33:25.21W 58:45:01.24

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT