



CODING TABLE

SID RNAV BOLAR 1B RWY 08					MACAPÁ / Alberto Alcolumbre, INTL (SBMQ)							SBMQ_SID_00D		09 JUL 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	Y	N/A	BOLAR	CF	76.77° Mag 57.33° True	N/A	N/A	N/A	N/A	N/A	3.00	N/A	OTHER	RNAV 1 or RNP 1
10	VUMBO	N/A	N/A	BOLAR	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	VUMBO	N	N/A	VUMBO	DF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
10	TILTO	N/A	N/A	BOLAR	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	TILTO	N	N/A	TILTO	TF	144.57° Mag 125.13° True	R	N/A	N/A	N/A	N/A	57.45	N/A	OTHER	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
BOLAR	N 00:04:58.32W 51:01:19.89
VUMBO	S 00:15:08.80W 51:34:15.40
TILTO	S 00:28:15.35W 50:14:25.69

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
08	N 00:03:20.67 W 51:03:51.15	47.80

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT