



CODING TABLE

IAC ILS Y RWY 16L					NATAL / Campo Augusto Severo, MIL (SBNT)							SBNT_IAC_00J		28 DEC 23	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	NT361	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	NT364	TF	231.55° Mag 210.91° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	APCH	N/A	N/A	NT363	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	NT364	TF	91.63° Mag 70.91° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	APCH	N/A	N/A	NT362	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	NT364	TF	161.60° Mag 140.93° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	FINAL	N/A	N/A	NT364	IF	N/A	N/A	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N	INT	NT366	CF	161.65° Mag 140.94° True	N/A	N/A	+1800	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	Y	INT	RW16L	CF	161.71° Mag 141.00° True	N/A	N/A	@203	N/A	N/A	5.00	-3.00	LTP	N/A
10	MA	N/A	N/A	N/A	VA	161.64° Mag 140.94° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	MA	Y	N/A	NT363	DF	N/A	R	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	RNAV 1 or RNP 1
30	MA	Y	N/A	NT363	HM	91.63° Mag 70.91° True	R	N/A	+3000	N/A	N/A	1.00 min	N/A	MAHF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NT362	S 05:41:37.70W 35:25:12.80
NT364	S 05:46:18.50W 35:21:25.20
NT361	S 05:41:08.20W 35:18:19.70
NT363	S 05:48:16.80W 35:27:06.50
NT366	S 05:50:12.50W 35:18:15.50
RW16L	S 05:54:06.60W 35:15:05.70

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT