



## CODING TABLE

IAC VOR Z RWY 12					NATAL / Campo Augusto Severo, MIL (SBNT)							SBNT_IAC_00K		05 OCT 23	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	NTL	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	NTL	NTL	FC	266.22° Mag 245.52° True	N/A	N/A	+2100	N/A	N/A	7.50	N/A	OTHER	N/A
30	APCH	N/A	NTL	ELANI	CF	114.69° Mag 93.99° True	R	N/A	+2000	N/A	N/A	N/A	N/A	FAF	N/A
10	FINAL	N/A	N/A	ELANI	IF	N/A	N/A	N/A	+2000	N/A	N/A	N/A	N/A	FAF	N/A
20	FINAL	N/A	NTL	NTL01*	CF	114.69° Mag 93.99° True	N/A	N/A	R853	N/A	N/A	3.58	-3.00	SDF	N/A
30	FINAL	Y	NTL	NTL07*	CF	114.69° Mag 93.99° True	N/A	N/A	@216	N/A	N/A	2.00	-3.00	FTP	N/A
10	MA	N/A	NTL	NTL	CA	140.00° Mag / 119.29° True	N/A	N/A	+2000	210	-	N/A	N/A	N/A	N/A
20	MA	N/A	NTL	NTL	DF	N/A	R	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	NTL	NTL	HM	320.00° Mag / 299.29° True	L	N/A	+3000	N/A	N/A	1.00 min	N/A	MAHF	N/A

\*Fictitious point: only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR NTL	S 05:54:30.00W 35:14:55.20
ELANI	S 05:54:04.81W 35:20:55.72
NTL07	S 05:54:28.24W 35:15:20.43
NTL01	S 05:54:19.85W 35:17:20.56

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT