



## CODING TABLE

IAC NDB RWY 22					PONTA PORÁ / Ponta Porã, INTL (SBPP)							SBPP_IAC_00D		11 JUN 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	FINAL	N/A	N/A	PTP	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	FINAL	N/A	PTP	PTP	FC	17.38° Mag 359.69° True	N/A	N/A	+3500	N/A	N/A	2.00 min	N/A	OTHER	N/A
30	FINAL	N/A	PTP	PTP02*	CF	226.02° Mag 208.33° True	R	N/A	@2177	N/A	N/A	N/A	N/A	FTP	N/A
10	MA	N/A	PTP	N/A	CA	226.02° Mag 208.33° True	N/A	N/A	+3500	230	-	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	N/A	DF	N/A	L	N/A	+4000	230	-	N/A	N/A	MAHF	N/A
30	MA	N/A	PTP	PTP	HM	46.02° Mag 28.33° True	R	N/A	+4000	230	-	1.00 min	N/A	MAHF	N/A

\*Fictitious point only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NDB PTP	S 22:33:00.27W 55:42:25.78
PTP02	S 22:32:24.89W 55:42:05.25

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT