



## CODING TABLE

IAC VOR Z RWY 06					SÃO LUÍS / Marechal Cunha Machado, INTL (SBSL)							SBSL_IAC_00M		09 JUL 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	ARSAL	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	SLI	LODEB	AF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	IF	N/A
10	APCH	N/A	N/A	UBLEV	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	SLI	LODEB	AF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	IF	N/A
10	FINAL	N/A	N/A	LODEB	IF	N/A	N/A	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	SLI	ARNID	CF	53.65° Mag 33.05° True	N/A	N/A	R1660	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	N/A	SLI	SLI01*	CF	53.65° Mag 33.05° True	N/A	N/A	@227	N/A	N/A	4.50	-3.00	FTP	N/A
10	MA	N/A	SLI	N/A	CA	53.65° Mag 33.05° True	N/A	N/A	+1300	220	-	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	N/A	VI	230.57° Mag 210.00° True	L	N/A	+4000	220	-	N/A	N/A	OTHER	N/A
30	MA	N/A	SLI	ARSAL	CF	278.66° Mag 258.06° True	R	N/A	+4000	220	-	N/A	N/A	MAHF	N/A
40	MA	N/A	SLI	ARSAL	HM	98.66° Mag 78.06° True	L	N/A	+4000	220	-	1.00 min	N/A	MAHF	N/A

\*Fictitious point: Only for coding purpose

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR/DME SLI	S 02:35:21.27W 44:14:23.89
LODEB	S 02:43:46.75W 44:19:51.00
ARNID	S 02:39:34.07W 44:17:07.47
SLI01	S 02:35:46.66W 44:14:40.32
ARSAL	S 02:37:26.00W 44:24:10.61
UBLEV	S 02:45:11.29W 44:12:19.70

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT