



CODING TABLE

STAR RNAV ANISE 1A - IBDAL 2A RWY 35R/35L					SÃO PAULO / Congonhas – Deputado Freitas Nobre (SBSP)							SBSP_STAR_02N		07 AUG 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	ANISE	N/A	N/A	ANISE	IF	N/A	N/A	-17000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	ANISE	N	N/A	SP091	TF	21.66° Mag / 359.93° True	N/A	-14000	N/A	N/A	N/A	12.43	N/A	OTHER	RNAV 1 or RNP 1
30	ANISE	N	N/A	SP111	TF	21.74° Mag / 359.97° True	N/A	N/A	N/A	N/A	N/A	9.99	N/A	OTHER	RNAV 1 or RNP 1
40	ANISE	N	N/A	OGTAL	TF	21.78° Mag / 359.97° True	N/A	N/A	+6000	N/A	N/A	22.17	N/A	IAF	RNAV 1 or RNP 1
10	IBDAL	N/A	N/A	IBDAL	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	IBDAL	N	N/A	MANLO	TF	278.87° Mag / 256.48° True	N/A	-19000	N/A	N/A	N/A	10.00	N/A	OTHER	RNAV 1 or RNP 1
30	IBDAL	N	N/A	SP033	TF	289.07° Mag / 266.74° True	N/A	N/A	N/A	N/A	N/A	43.89	N/A	OTHER	RNAV 1 or RNP 1
40	IBDAL	N	N/A	ESUNI	TF	287.67° Mag / 265.62° True	N/A	N/A	+6000	N/A	N/A	13.69	N/A	IAF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
ANISE	S 24:36:07.80W 46:37:31.20
SP091	S 24:23:39.80W 46:37:32.23
SP111	S 24:13:38.11W 46:37:32.62
OGTAL	S 23:51:23.29W 46:37:33.47
IBDAL	S 23:45:29.47W 45:13:53.44
MANLO	S 23:47:49.89W 45:24:29.69
SP033	S 23:50:12.81W 46:12:17.07
ESUNI	S 23:51:15.00W 46:27:10.20

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT.