



CODING TABLE

IAC RNP RWY 26					GOIANÁ / Presidente Itamar Franco (SBZM)							SBZM_IAC_00D		29 OCT 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	ZM003	IF	N/A	N/A	N/A	+6000	N/A	N/A	N/A	N/A	IAF	RNP APCH
20	APCH	N	N/A	ZM002	TF	186.82° Mag 163.62° True	N/A	N/A	+4600	N/A	N/A	5.99	N/A	IF	RNP APCH
10	FINAL	N/A	N/A	ZM002	IF	N/A	N/A	N/A	+4600	N/A	N/A	N/A	N/A	IF	RNP APCH
20	FINAL	N	N/A	ZM031	TF	240.83° Mag 217.63° True	N/A	N/A	R2970	N/A	N/A	6.00	N/A	FAF	RNP APCH
30	FINAL	Y	N/A	RWY26	TF	256.45° Mag 233.28° True	N/A	N/A	@1377	N/A	N/A	4.99	-3.00	LTP	RNP APCH
10	MA	N/A	N/A	N/A	CA	256.38° Mag 233.22° True	N/A	N/A	+3000	N/A	N/A	N/A	N/A	OTHER	RNP APCH
20	MA	Y	N/A	ZM003	DF	N/A	R	N/A	+6000	N/A	N/A	N/A	N/A	MAHF	RNP APCH
30	MA	Y	N/A	ZM003	HM	186.82° Mag 163.62° True	L	N/A	+6000	N/A	N/A	1.00 min	N/A	MAHF	RNP APCH

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
ZM003	S 21:16:51.60W 43:03:24.00
ZM002	S 21:22:37.80W 43:01:35.40
ZM031	S 21:27:24.00W 43:05:31.20
RWY26	S 21:30:23.62W 43:09:48.61

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT