



CODING TABLE

STAR RNAV VACAR 1B RWY 16L					NATAL / Campo Augusto Severo, MIL (SBNT)							SBNT_STAR_01N		24 FEB 22	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	VACAR	N	N/A	VACAR	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	VACAR	N	N/A	ARPUK	TF	35.89° Mag 14.17° True	N/A	N/A	+17000	N/A	N/A	58.94	N/A	OTHER	RNAV 1 or RNP 1
30	VACAR	N	N/A	BIVIV	TF	36.12° Mag 14.60° True	N/A	N/A	+10000	N/A	N/A	32.70	N/A	OTHER	RNAV 1 or RNP 1
40	VACAR	N	N/A	IVSIK	TF	55.28° Mag 33.91° True	N/A	N/A	N/A	N/A	N/A	24.30	N/A	OTHER	RNAV 1 or RNP 1
50	VACAR	N	N/A	NT363	TF	93.51° Mag 72.17° True	R	N/A	+4000	N/A	N/A	6.85	N/A	IAF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VACAR	S 07:39:55.20W 36:10:07.20
ARPUK	S 06:42:29.73W 35:55:34.95
BIVIV	S 06:10:41.16W 35:47:17.59
IVSIK	S 05:50:23.40W 35:33:39.60
NT363	S 05:48:16.80W 35:27:06.50

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE