



CODING TABLE

IAC VOR Z RWY 12					NATAL / Augusto Severo, MIL (SBNT)							SBNT_IAC_00K		12 AUG 21	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	NTL	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	NTL	NTL	FC	260.95° Mag / 239.65° True	R	N/A	+2100	N/A	N/A	7.50	N/A	OTHER	N/A
30	APCH	N/A	NTL	ELANI	CF	115.29° Mag / 93.99° True	R	N/A	R2000	N/A	N/A	N/A	N/A	FAF	N/A
10	FINAL	N/A	N/A	ELANI	IF	115.29° Mag / 93.99° True	N/A	N/A	R2000	N/A	N/A	N/A	N/A	FAF	N/A
20	FINAL	N/A	NTL	NTL01 *	CF	115.29° Mag / 93.99° True	N/A	N/A	R853	N/A	N/A	3.58	-3.00	SDF	N/A
30	FINAL	N/A	NTL	NTL07 *	CF	115.29° Mag / 93.99° True	N/A	N/A	@216	N/A	N/A	2.00	-3.00	FTP	N/A
10	MA	N/A	NTL	N/A	CA	140.00° Mag / 118.70° True	N/A	N/A	+1000	210	-	N/A	N/A	MAHF	N/A
20	MA	N/A	N/A	NTL	DF	N/A	R	N/A	+4000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	NTL	NTL	HM	320.00° Mag / 298.70° True	L	N/A	+4000	N/A	N/A	N/A	N/A	MAHF	N/A

* Fictitious point only for coding purpose.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NTL	S 05:54:30.00W 35:14:55.20
ELANI	S 05:54:04.81W 35:20:55.72
NTL01	S 05:54:19.85W 35:17:20.56
NTL07	S 05:54:28.24W 35:15:20.43

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT