



CODING TABLE

IAC NDB Z RWY 10					CABO FRIO / Cabo Frio, INTL (SBCB)							SBCB_IAC_00C	21 APR 22		
Seq Num	IAP Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role Of TheFix	Navigation Specification
10	FINAL	N/A	N/A	BFR	IF	N/A	N/A	N/A	+4100	N/A	N/A	N/A	N/A	IAF	N/A
20	FINAL	N/A	BFR	N/A	PI	284.34° Mag / 261.01° True	N/A	N/A	+2500	N/A	N/A	2.66 min	N/A	N/A	N/A
30	FINAL	N/A	BFR	BFR01*	CF	104.33° Mag / 81.00° True	R	N/A	@59	N/A	N/A	N/A	-3.0	FTP	N/A
10	MA	N/A	BFR	N/A	VA	104.32° Mag / 81.00° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	N/A	N/A
20	MA	N/A	BFR	BFR	DF	N/A	R	N/A	+4100	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	BFR	BFR	HM	284.34° Mag / 261.01° True	L	N/A	+4100	N/A	N/A	N/A	N/A	MAHF	N/A

*Fictitious point only for coding purposes

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
BFR	S 22:55:24.00W 42:04:17.40
BFR01	S 22:55:29.96W 42:04:58.07

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT