



## CODING TABLE

SID RNAV IBDAL 1A - SURDO 1A					ANGRA DOS REIS / Angra dos Reis (SDAG)							SDAG_SID_00B		18 APR 24	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	N/A	N/A	AG004	IF	N/A	N/A	N/A	+600	N/A	N/A	N/A	N/A	IDF	RNAV 1 or RNP 1
20	RWY	N	N/A	AG012	TF	281.90° Mag 259.40° True	N/A	N/A	N/A	N/A	N/A	2.00	3.43	OTHER	RNAV 1 or RNP 1
30	RWY	N	N/A	AG001	TF	212.46° Mag 190.00° True	N/A	N/A	N/A	N/A	N/A	5.70	3.43	OTHER	RNAV 1 or RNP 1
10	SURDO	N/A	N/A	AG001	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	SURDO	N	N/A	SURDO	TF	126.17° Mag 103.49° True	N/A	N/A	N/A	N/A	N/A	23.01	N/A	OTHER	RNAV 1 or RNP 1
10	IBDAL	N/A	N/A	AG001	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	IBDAL	N	N/A	IBDAL	TF	250.30° Mag 228.19° True	N/A	N/A	N/A	N/A	N/A	61.70	N/A	OTHER	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
AG004	S 22:58:06.12W 44:20:47.81
AG012	S 22:58:27.29W 44:22:54.53
AG001	S 23:04:04.85W 44:24:01.21
SURDO	S 23:09:30.52W 43:59:42.97
IBDAL	S 23:45:29.47W 45:13:53.44

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE