



CODING TABLE

IAC ILS W RWY 08					BOA VISTA / Atlas Brasil Cantanhede, INTL (SBBV)							SBBV_IAC_00G		08 AUG 24	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	BV003	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	VULOT	TF	148.45° Mag 132.39° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	APCH	N/A	N/A	BV006	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	VULOT	TF	78.44° Mag 62.39° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	APCH	N/A	N/A	BV004	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	VULOT	TF	8.50° Mag 352.40° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	FINAL	N/A	N/A	VULOT	IF	N/A	N/A	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	IBV	ABREU	CF	78.58° Mag 62.42° True	N/A	N/A	R1910	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	Y	IBV	RWY08	CF	78.58° Mag 62.42° True	N/A	N/A	@310	N/A	N/A	5.00	-3.00	LTP	N/A
10	MA	N/A	N/A	N/A	CA	78.51° Mag 62.36° True	N/A	N/A	+1500	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	MA	Y	N/A	BV003	DF	N/A	L	N/A	+4000	N/A	N/A	N/A	N/A	MAHF	RNAV 1 or RNP 1
30	MA	Y	N/A	BV003	HM	148.49° Mag 133.04° True	L	N/A	+4000	N/A	N/A	1.00 min	N/A	MAHF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VULOT	N 02:45:53.27W 60:50:57.36
ABREU	N 02:48:10.11W 60:46:30.22
BV003	N 02:50:00.00W 60:55:20.48
BV006	N 02:43:09.03W 60:56:17.92
BV004	N 02:39:54.19W 60:50:13.55
RWY08	N 02:50:26.93 W 60:42:03.05

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT