



CODING TABLE

IAC NDB RWY 12				SANTO ÂNGELO / Santo Ângelo (SBNM)								SBNM_IAC_00J	16 JUN 22		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	FINAL	N/A	N/A	SAN	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	FINAL	N/A	SAN	SAN	FC	260.58° Mag 244.71° True	N/A	N/A	+2300	N/A	N/A	2.00 min	N/A	OTHER	N/A
30	FINAL	N/A	SAN	SAN03*	CF	107.72° Mag 91.85° True	R	N/A	@1072	N/A	N/A	N/A	N/A	FTP	N/A
10	MA	N/A	SAN	N/A	CA	107.73° Mag 91.85° True	N/A	N/A	+2100	N/A	N/A	N/A	N/A	N/A	N/A
20	MA	N/A	N/A	SAN	DF	N/A	L	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	SAN	SAN	HM	261.00° Mag 245.13° True	L	N/A	+3000	N/A	N/A	1.00 min	N/A	MAHF	N/A

(*) Fictitious point for coding purposes only.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
SAN03	S 28:16:44.95W 54:10:39.02
SAN	S 28:16:45.52W 54:10:18.99

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT