



CODING TABLE

IAC VOR Z RWY 16R					NATAL / Campo Augusto Severo, MIL (SBNT)							SBNT_IAC_00M		24 FEB 22	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	NTL	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	NTL	NTL	FC	347.00° Mag / 325.70° True	N/A	N/A	+1900	200	-	8.00	N/A	OTHER	N/A
30	APCH	N/A	NTL	VAKAN	CF	149.00° Mag / 127.70° True	L	N/A	+1800	N/A	N/A	N/A	N/A	FAF	N/A
10	FINAL	N/A	NTL	VAKAN	IF	N/A	N/A	N/A	+1800	N/A	N/A	N/A	N/A	FAF	N/A
20	FINAL	N/A	NTL	NTL03*	CF	149.00° Mag / 127.70° True	N/A	N/A	R847	N/A	N/A	3.00	-3.00	SDF	N/A
30	FINAL	N/A	NTL	NTL16*	CF	149.00° Mag / 127.70° True	N/A	N/A	@210	N/A	N/A	2.00	-3.00	FTP	N/A
10	MA	N/A	NTL	N/A	CA	168.00° Mag / 146.70° True	N/A	N/A	+1000	200	-	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	NTL	DF	N/A	R	N/A	+4000	200	-	N/A	N/A	MAHF	N/A
30	MA	N/A	NTL	NTL	HM	10.00° Mag / 348.70° True	L	N/A	+4000	N/A	N/A	1.00 min	N/A	MAHF	N/A

*Fictitious point: Only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR NTL	S 05:54:30.00W 35:14:55.20
VAKAN	S 05:51:12.14W 35:19:10.85
NTL03*	S 05:53:02.93W 35:16:47.72
NTL16*	S 05:54:16.66W 35:15:12.44

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT