



CODING TABLE

Identification	Aerodrome	Chart Code	AIRAC AMDT
SID RNAV ISNUV 1A RWY 16	BELO HORIZONTE / Tancredo Neves, INTL (SBCF)	SBCF_SID_01R	26 JAN 23

Seq	Transition	Path Terminator	Navaid / Fix / WPT	Type / Function	Flyover (Y/N)	Navaid	Course Mag (True)	Dist (NM)	Turn (L/R)	IAS (KT)	Altitude (FT)	Gradient (%)	Perform.
RWY 16													
010	Runway	CA	---	---	---	---	162 (138.8)	---	---	---	+4700	---	RNAV 1 or RNP 1
020	Runway	DF	VUPER	---	N	---	---	---	L	---	-9000	---	RNAV 1 or RNP 1
030	Runway	TF	ISNUV	---	N	---	074 (050.7)	10.0	R	---	-10000	---	RNAV 1 or RNP 1
TRNS ANLES													
010	Enroute	IF	ISNUV	---	N	---	---	---	---	---	-10000	---	RNAV 1 or RNP 1
020	Enroute	TF	ANLES	---	N	---	046 (023.3)	21.1	L	---	---	---	RNAV 1 or RNP 1
TRNS KOKSU													
010	Enroute	IF	ISNUV	---	N	---	---	---	---	---	-10000	---	RNAV 1 or RNP 1
020	Enroute	TF	KOKSU	---	N	---	085 (062.1)	17.4	R	---	---	---	RNAV 1 or RNP 1

TRNS SALVI													
010	Enroute	IF	ISNUV	---	N	---	---	---	---	---	-10000	---	RNAV 1 or RNP 1
020	Enroute	TF	ANLES	---	N	---	046 (023.3)	21.1	L	---	---	---	RNAV 1 or RNP 1
030	Enroute	TF	SALVI	---	N	---	042 (019.2)	17.9	L	---	-19000	---	RNAV 1 or RNP 1
TRNS EVTEK													
010	Enroute	IF	ISNUV	---	N	---	---	---	---	---	-10000	---	RNAV 1 or RNP 1
020	Enroute	TF	ANPEK	---	N	---	111 (087.3)	21.4	R	---	+15000	---	RNAV 1 or RNP 1
030	Enroute	TF	EVTEK	---	N	---	111 (087.1)	41.5	---	---	---	---	RNAV 1 or RNP 1

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
16	S 19:39:00.00W 43:57:13.22	2721

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
EVTEK	S 19:27:46.80W 42:28:46.20
ANLES	S 19:11:21.60W 43:26:24.00
ANPEK	S 19:29:48.30W 43:12:36.87
ISNUV	S 19:30:47.43W 43:35:13.32
KOKSU	S 19:22:38.40W 43:18:58.20
SALVI	S 18:54:25.80W 43:20:12.00
VUPER	S 19:37:08.88W 43:43:24.60

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
=	MANDATORY
	RECOMMENDED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT