



CODING TABLE

STAR RNAV TENUB 1A RWY 13					FORTALEZA / Pinto Martins, INTL (SBFZ)							SBFZ_STAR_01M	19 MAR 26		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	TENUB	N/A	N/A	TENUB	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	TENUB	N	N/A	FZ019	TF	349.21° Mag 328.48° True	N/A	N/A	N/A	N/A	N/A	13.44	N/A	OTHER	RNAV 1 or RNP 1
30	TENUB	N	N/A	FZ379	TF	346.91° Mag 326.22° True	N/A	N/A	N/A	N/A	N/A	25.24	N/A	OTHER	RNAV 1 or RNP 1
40	TENUB	N	N/A	FZ059	TF	305.42° Mag 284.82° True	N/A	N/A	+7000	N/A	N/A	14.13	N/A	OTHER	RNAV 1 or RNP 1
50	TENUB	N	N/A	FZ027	TF	304.93° Mag 284.30° True	N/A	N/A	+4200	N/A	N/A	11.33	N/A	IAF	RNAV 1 or RNP 1

STAR RNAV DOTKU 1A RWY 13					FORTALEZA / Pinto Martins, INTL (SBFZ)							SBFZ_STAR_01M	19 MAR 26		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	DOTKU	N/A	N/A	DOTKU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	DOTKU	N	N/A	FZ024	TF	50.26° Mag 29.39° True	N/A	N/A	N/A	N/A	N/A	8.61	N/A	OTHER	RNAV 1 or RNP 1
30	DOTKU	N	N/A	FZ058	TF	49.94° Mag 29.12° True	N/A	-9000	N/A	N/A	N/A	11.27	N/A	OTHER	RNAV 1 or RNP 1
40	DOTKU	N	N/A	FZ026	IF	39.49° Mag 18.74° True	N/A	-7000	N/A	N/A	N/A	7.05	N/A	OTHER	RNAV 1 or RNP 1
50	DOTKU	N	N/A	FZ027	TF	56.25° Mag 35.53° True	N/A	N/A	+4200	N/A	N/A	12.68	N/A	IAF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
TENUB	S 04:28:27.78 W 037:58:05.37
FZ019	S 04:16:57.11 W 038:05:07.28
FZ379	S 03:55:52.20 W 038:19:09.60
FZ059	S 03:52:14.42 W 038:32:49.39
FZ027	S 03:49:25.54 W 038:43:49.15
DOTKU	S 04:23:55.83 W 039:03:10.41
FZ024	S 04:16:23.71 W 038:58:56.77
FZ058	S 04:06:30.02 W 038:53:27.40
FZ026	S 03:59:47.76 W 038:51:11.54

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT