



CODING TABLE

IAC VOR RWY 05					MOSSORÓ / Dix-Sept Rosado (SBMS)							SBMS_IAC_00C		13 AUG 20	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	MSS	UMDAV	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	MSS	MS010 (*)	AF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A
30	APCH	N/A	MSS	KUKAT	CF	41.38° Mag	N/A	N/A	+1700	N/A	N/A	2.21	N/A	IF	N/A
10	APCH	N/A	MSS	DANBU	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	MSS	MS017 (*)	AF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A
30	APCH	N/A	MSS	KUKAT	CF	41.38° Mag	N/A	N/A	+1700	N/A	N/A	2.21	N/A	IF	N/A
10	FINAL	N/A	MSS	KUKAT	IF	N/A	N/A	N/A	+1700	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	MSS	NEDEP	CF	41.32° Mag	N/A	N/A	+1700	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	N/A	MSS	RWY05	CF	41.29° Mag	N/A	N/A	@660	N/A	N/A	5.00	-3.00	MAPT	N/A
10	MA	N/A	MSS	ENRIK	CF	41.19° Mag	N/A	N/A	+3000	N/A	N/A	15.80	N/A	MAHF	N/A
20	MA	N/A	MSS	ENRIK	HM	41.19° Mag	L	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A

* Only for coding purpose.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
UMDAV	S 05:24:52.73W 37:21:15.04
MS010	S 05:24:06.70W 37:26:18.36
DANBU	S 05:21:31.98W 37:30:35.99
MS017	S 05:24:07.10W 37:26:18.51
KUKAT	S 05:22:01.96W 37:25:33.18
NEDEP	S 05:17:18.56W 37:23:50.69
RWY05	S 05:12:35.14W 37:22:08.22
ENRIK	S 04:57:40.00W 37:16:44.77

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT