



CODING TABLE

SID RNAV NUNVU 2A RWY 23					JAGUARUNA / Regional Sul (SBJA)							SBJA_SID_00D		21 APR 22	
Seq Num	IAP Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role Of TheFix	Navigation Specification
10	RWY	Y	N/A	NUNVU	CF	232.43° Mag 213.87° True	N/A	N/A	N/A	N/A	N/A	9.80	N/A	OTHER	RNAV or RNP 1
10	TIMVI	N/A	N/A	NUNVU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV or RNP 1
20	TIMVI	N	N/A	TIMVI	TF	280.49° Mag 262.32° True	N/A	N/A	N/A	N/A	N/A	34.14	N/A	OTHER	RNAV or RNP 1
10	BUTOK	N/A	N/A	NUNVU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV or RNP 1
20	BUTOK	N	N/A	TIMVI	TF	280.49° Mag 262.32° True	N/A	N/A	N/A	N/A	N/A	34.14	N/A	OTHER	RNAV or RNP 1
30	BUTOK	N	N/A	BUTOK	TF	248.09° Mag 230.26° True	N/A	N/A	N/A	N/A	N/A	26.78	N/A	OTHER	RNAV or RNP 1
10	UKBIX	N/A	N/A	NUNVU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV or RNP 1
20	UKBIX	N	N/A	UKBIX	TF	335.36° Mag 317.07° True	R	N/A	N/A	N/A	N/A	85.44	N/A	OTHER	RNAV or RNP 1
10	FLN	N/A	N/A	NUNVU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV or RNP 1
20	FLN	N	N/A	FLN	DF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV or RNP 1
10	ELAKA	N/A	N/A	NUNVU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV or RNP 1
20	ELAKA	N	N/A	ELAKA	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR FLN	S 27:40:11.70W 48:32:25.63
UKBIX	S 27:46:56.69W 50:16:35.43
NUNVU	S 28:49:24.31W 49:10:20.28
TIMVI	S 28:54:04.28W 49:48:51.64
ELAKA	S 27:42:08.25W 49:01:46.50
BUTOK	S 29:11:16.20W 50:12:19.80

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
23	S 28:41:12.82W 49:04:06.20	110