



## CODING TABLE

IAC ILS W RWY 08					BOA VISTA / Atlas Brasil Cantanhede, INTL (SBBV)							SBBV_IAC_00G		15 MAY 25	
mar	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	BV007	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	VULOT	TF	168.87° Mag 152.73° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	APCH	N/A	N/A	BV006	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	VULOT	TF	79.14° Mag 63.00° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	APCH	N/A	N/A	BV022	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	VULOT	TF	348.87° Mag 332.73° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	FINAL	N/A	N/A	VULOT	IF	N/A	N/A	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	IBV	ABREU	CF	79.18° Mag 63.01° True	N/A	N/A	R1910	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	N/A	IBV	RWY08	CF	79.21° Mag 63.01° True	N/A	N/A	@310	N/A	N/A	5.00	-3.00	LTP	N/A
10	MA	N/A	N/A	N/A	CA	78.51° Mag 62.29° True	N/A	N/A	+1500	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	MA	Y	N/A	BV007	DF	N/A	L	N/A	+4000	N/A	N/A	N/A	N/A	MAHF	RNAV 1 or RNP 1
30	MA	Y	N/A	BV007	HM	168.84° Mag 152.73° True	L	N/A	+4000	N/A	N/A	1.00 min	N/A	MAHF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VULOT	N 02:45:53.27W 60:50:57.36
ABREU	N 02:48:10.11W 60:46:30.22
BV007	N 02:51:14.91W 60:53:42.26
BV006	N 02:43:09.03W 60:56:17.92
BV022	N 02:40:31.62W 60:48:12.49
RWY08	N 02:50:26.93W 60:42:03.05

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT