



## CODING TABLE

STAR RNAV RAXIT 1C RWY 15/33					JOINVILLE / Lauro Carneiro de Loyola (SBJV)							SBJV_STAR_01J		02 NOV 23	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RAXIT	N/A	N/A	RAXIT	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	RAXIT	N	N/A	JV113	TF	238.22° Mag / 216.99° True	N/A	-17000	N/A	N/A	N/A	57.10	N/A	OTHER	RNAV 1 or RNP 1
30	RAXIT	N	N/A	JV114	TF	238.04° Mag / 217.28° True	N/A	N/A	N/A	N/A	N/A	5.28	N/A	OTHER	RNAV 1 or RNP 1
40	RAXIT	N	N/A	JV116	TF	208.12° Mag / 187.40° True	N/A	-15000	N/A	N/A	N/A	4.80	N/A	OTHER	RNAV 1 or RNP 1
50	RAXIT	N	N/A	JV117	TF	208.10° Mag / 187.41° True	N/A	N/A	+14000	N/A	N/A	5.33	N/A	OTHER	RNAV 1 or RNP 1
60	RAXIT	N	N/A	JV118	TF	208.07° Mag / 187.41° True	N/A	-12000	N/A	N/A	N/A	11.66	N/A	OTHER	RNAV 1 or RNP 1
10	RWY15	N/A	N/A	JV118	IF	N/A	N/A	-12000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	RWY15	N	N/A	ANDAM	TF	247.35° Mag / 226.75° True	N/A	N/A	+6000	N/A	N/A	17.29	N/A	IAF	RNAV 1 or RNP 1
10	RWY33	N/A	N/A	JV118	IF	N/A	N/A	-12000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	RWY33	N	N/A	JV119	TF	206.05° Mag / 185.45° True	N/A	-8000	N/A	N/A	N/A	16.73	N/A	OTHER	RNAV 1 or RNP 1
30	RWY33	N	N/A	ARNED	TF	216.29° Mag / 195.78° True	N/A	N/A	+4000	N/A	N/A	22.62	N/A	IAF	RNAV 1 or RNP 1

dent	Latitude / Longitude (WGS84) DD:MM:SS.SS
JV118	S 25:36:47.48W 48:25:59.51
ANDAM	S 25:48:39.69W 48:39:56.74
JV119	S 25:53:29.75W 48:27:45.32
ARNED	S 26:15:19.79W 48:34:35.83
RAXIT	S 24:25:13.89W 47:41:29.10
JV113	S 25:10:53.87W 48:19:21.43
JV114	S 25:15:06.83W 48:22:53.18
JV116	S 25:19:53.46W 48:23:34.14
JV117	S 25:25:11.64W 48:24:19.68

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT