



CODING TABLE

SID RNAV GATOX 1A RWY 34					BELO HORIZONTE / Tancredo Neves, INTL (SBCF)							SBCF_SID_01W		26 JAN 23	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	Y	N/A	CF012	CF	341.78° Mag / 318.80° True	N/A	N/A	N/A	N/A	N/A	4.30	N/A	OTHER	RNAV 1 or RNP 1
20	RWY	N	N/A	DOVRU	TF	98.05° Mag / 75.00° True	R	-8000	N/A	230	-	12.26	N/A	OTHER	RNAV 1 or RNP 1
30	RWY	N	N/A	GATOX	TF	97.94° Mag / 74.82° True	N/A	-10000	N/A	N/A	N/A	12.74	N/A	OTHER	RNAV 1 or RNP 1
10	ANLES	N/A	N/A	GATOX	IF	N/A	N/A	-10000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	ANLES	N	N/A	ANLES	TF	55.04° Mag / 31.87° True	L	N/A	+15000	N/A	N/A	18.40	N/A	OTHER	RNAV 1 or RNP 1
10	KOKSU	N/A	N/A	GATOX	IF	N/A	N/A	-10000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	KOKSU	N	N/A	KOKSU	TF	98.47° Mag / 75.27° True	R	N/A	+15000	N/A	N/A	17.30	N/A	OTHER	RNAV 1 or RNP 1
10	SALVI	N/A	N/A	GATOX	IF	N/A	N/A	-10000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	SALVI	N	N/A	ANLES	TF	55.04° Mag / 31.87° True	L	N/A	+15000	N/A	N/A	18.40	N/A	OTHER	RNAV 1 or RNP 1
30	SALVI	N	N/A	SALVI	TF	42.38° Mag / 19.18° True	L	-19000	N/A	N/A	N/A	17.86	N/A	OTHER	RNAV 1 or RNP 1
10	EVTEK	N/A	N/A	GATOX	IF	N/A	N/A	-10000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	EVTEK	N	N/A	WH018	TF	114.68° Mag / 91.46° True	R	N/A	+15000	N/A	N/A	20.95	N/A	OTHER	RNAV 1 or RNP 1
30	EVTEK	N	N/A	EVTEK	TF	113.53° Mag / 90.10° True	L	N/A	N/A	N/A	N/A	43.22	N/A	OTHER	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
ANLES	S 19:11:21.60W 43:26:24.00
DOVRU	S 19:30:22.80W 43:49:42.00
GATOX	S 19:27:02.40W 43:36:40.80
KOKSU	S 19:22:38.40W 43:18:58.20
SALVI	S 18:54:25.80W 43:20:12.00
WH018	S 19:27:36.08W 43:14:30.73
CF012	S 19:33:35.71W 44:02:13.06
EVTEK	S 19:27:46.80W 42:28:46.20

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
34	S 19:36:50.34 W 43:59:13.08	2713

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT