



CODING TABLE

SID NTL 2A RWY 12					NATAL / Campo Augusto Severo, MIL (SBNT)							SBNT_SID_00D		24 FEB 22	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	N/A	N/A	N/A	VA	120.30° Mag 98.99° True	N/A	N/A	+600	210	-	N/A	N/A	OTHER	N/A
20	RWY	N/A	NTL	NTL	DF	N/A	R	N/A	N/A	210	-	N/A	N/A	OTHER	N/A
10	SIRED	N/A	N/A	NTL	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A
20	SIRED	N/A	NTL	NTL02*	CF	49.50° Mag 28.20° True	N/A	-4000	N/A	N/A	N/A	7.01	N/A	OTHER	N/A
30	SIRED	N/A	NTL	SIRED	CF	49.50° Mag 28.20° True	N/A	N/A	N/A	N/A	N/A	33.00	N/A	OTHER	N/A
10	OGPER	N/A	N/A	NTL	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A
20	OGPER	N/A	NTL	NTL04*	CF	75.69° Mag 54.38° True	N/A	-4000	N/A	N/A	N/A	7.00	N/A	OTHER	N/A
30	OGPER	N/A	NTL	OGPER	CF	75.66° Mag 54.36° True	N/A	N/A	N/A	N/A	N/A	33.00	N/A	OTHER	N/A

*Fictitious point: only for coding purposes.

SID NTL 2B RWY 16L/16R					NATAL / Campo Augusto Severo, MIL (SBNT)							SBNT_SID_00D		24 FEB 22	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	N/A	N/A	N/A	VA	162.32° Mag 141.01° True	N/A	N/A	+600	210	-	N/A	N/A	OTHER	N/A
20	RWY	N/A	NTL	NTL	DF	N/A	R	N/A	N/A	210	-	N/A	N/A	OTHER	N/A
10	SIRED	N/A	N/A	NTL	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A
20	SIRED	N/A	NTL	NTL02*	CF	49.50° Mag 28.20° True	N/A	-4000	N/A	N/A	N/A	7.01	N/A	OTHER	N/A
30	SIRED	N/A	NTL	SIRED	CF	49.50° Mag 28.20° True	N/A	N/A	N/A	N/A	N/A	33.00	N/A	OTHER	N/A
10	OGPER	N/A	N/A	NTL	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A

20	OGPER	N/A	NTL	NTL04*	CF	75.69° Mag 54.38° True	N/A	-4000	N/A	N/A	N/A	7.00	N/A	OTHER	N/A
30	OGPER	N/A	NTL	OGPER	CF	75.66° Mag 54.36° True	N/A	N/A	N/A	N/A	N/A	33.00	N/A	OTHER	N/A

*Fictitious point: only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR NTL	S 05:54:30.00W 35:14:55.20
NTL02*	S 05:48:18.05W 35:11:36.07
SIREN	S 05:19:05.20W 34:55:59.20
NTL04*	S 05:50:24.08W 35:09:12.47
OGPER	S 05:31:03.60W 34:42:19.20

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
12	S 05:54:41.99W 35:14:22.34	145.44
16R	S 05:55:12.50W 35:14:45.67	151.35
16L	S 05:55:12.31W 35:14:12.41	138.29

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT