



CODING TABLE

IAC VOR RWY 04					UBERLÂNDIA / Ten Cel Av César Bombonato (SBUL)							SBUL_IAC_00D	30 DEC 21		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	ULD	ULD	IF	N/A	N/A	N/A	+6000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	ULD	ULD	FC	267.40° Mag 245.89° True	N/A	N/A	+4800	N/A	N/A	7.00	N/A	N/A	N/A
30	APCH	N/A	ULD	GUVIR	CF	48.62° Mag 27.11° True	L	N/A	R4730	N/A	N/A	N/A	N/A	FAF	N/A
10	FINAL	N/A	N/A	GUVIR	IF	N/A	N/A	N/A	R4730	N/A	N/A	N/A	N/A	FAF	N/A
20	FINAL	N/A	ULD	RWY04	CF	48.62° Mag 27.11° True	N/A	N/A	@3136	N/A	N/A	5.00	-3.00	LTP	N/A
10	MA	N/A	ULD	N/A	CA	48.62° Mag 27.11° True	N/A	N/A	+5000	N/A	N/A	N/A	N/A	N/A	N/A
20	MA	N/A	ULD	ULD	DF	N/A	L	N/A	+6000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	ULD	ULD	HM	267.40° Mag 245.89° True	R	N/A	+6000	N/A	N/A	N/A	N/A	MAHF	N/A

(*) FICTITIOUS POINT. Only for coding purpose.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
ULD	S 18:52:35.80 W 48:13:16.68
GUVIR	S 18:58:00.11 W 48:16:11.20
RWY04	S 18:53:32.06 W 48:13:46.94

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT