



## CODING TABLE

IAC RNP S RWY 10L (AR)					SÃO PAULO / Guarulhos - Governador André Franco Montoro, INTL (SBGR)							SBGR_IAC_05A		25 JAN 24	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	SANPA	IF	N/A	N/A	N/A	+8000	N/A	N/A	N/A	N/A	IAF	RNP 1.0
20	APCH	N	N/A	GR037	TF	175.00° Mag 153.33° True	N/A	N/A	+7000	210	-	4.41	N/A	OTHER	RNP 1.0
30	APCH	N/A	N/A	GR031	RF	N/A	R	N/A	+5200	180	-	6.44	N/A	IF	RNP 1.0
N/A	N/A	N/A	N/A	GR039*	N/A	N/A	N/A	N/A	N/A	N/A	N/A	ARC RADIUS 4.00	N/A	N/A	N/A
10	APCH	N/A	N/A	ITAVO	IF	N/A	N/A	N/A	+8000	N/A	N/A	N/A	N/A	IAF	RNP 1.0
20	APCH	N	N/A	GR034	TF	351.02° Mag 329.33° True	N/A	N/A	+7000	210	-	6.00	N/A	OTHER	RNP 1.0
30	APCH	N/A	N/A	GR031	RF	N/A	L	N/A	+5200	180	-	5.85	N/A	IF	RNP 1.0
N/A	N/A	N/A	N/A	GR042*	N/A	N/A	N/A	N/A	N/A	N/A	N/A	ARC RADIUS 4.00	N/A	N/A	N/A
10	FINAL	N/A	N/A	GR031	IF	N/A	N/A	N/A	+5200	180	-	N/A	N/A	IF	RNP 1.0
20	FINAL	N/A	N/A	GR029	RF	N/A	L	N/A	R4800	N/A	N/A	2.50	N/A	FAF	RNP 1.0
N/A	N/A	N/A	N/A	GR038*	N/A	N/A	N/A	N/A	N/A	N/A	N/A	ARC RADIUS 2.50	N/A	N/A	N/A
30	FINAL	N/A	N/A	GR028	RF	N/A	L	N/A	R3154	N/A	N/A	5.00	-3.10	FROP	RNP 0.3
N/A	N/A	N/A	N/A	GR038	N/A	N/A	N/A	N/A	N/A	N/A	N/A	ARC RADIUS 2.50	N/A	N/A	N/A
40	FINAL	Y	N/A	RW10L	TF	95.35° Mag 73.70° True	N/A	N/A	@2495	N/A	N/A	2.00	-3.10	LTP	RNP 0.3
10	MA	N	N/A	GR032	TF	95.35° Mag 73.70° True	N/A	-6000	N/A	190	-	5.50	N/A	OTHER	RNP 1.0
20	MA	N/A	N/A	GR044	RF	N/A	L	N/A	N/A	190	-	8.53	N/A	OTHER	RNP 1.0
N/A	N/A	N/A	N/A	GR743*	N/A	N/A	N/A	N/A	N/A	N/A	N/A	ARC RADIUS 3.58	N/A	N/A	N/A

30	MA	N	N/A	GR047	TF	319.03° Mag 297.30° True	N/A	N/A	N/A	N/A	N/A	3.58	N/A	OTHER	RNP 1.0
40	MA	Y	N/A	SANPA	TF	321.38° Mag 299.67° True	N/A	N/A	+8000	N/A	N/A	7.43	N/A	MAHF	RNP 1.0
50	MA	Y	N/A	SANPA	HM	175.00° Mag 153.33° True	R	N/A	+8000	N/A	N/A	1.00 min	N/A	MAHF	RNP 1.0

\*Fictitious point: Only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
GR031	S 23:21:54.88W 46:32:55.42
GR029	S 23:23:50.19W 46:34:29.41
GR038	S 23:24:11.93W 46:31:48.06
GR028	S 23:26:36.39W 46:31:02.30
GR032	S 23:24:29.49W 46:23:12.74
GR044	S 23:17:50.80W 46:22:31.34
GR743	S 23:21:02.49W 46:24:18.51
GR047	S 23:16:11.81W 46:25:58.83
SANPA	S 23:12:30.33W 46:32:59.11
GR037	S 23:16:27.49W 46:30:50.18
GR039	S 23:18:15.57W 46:34:43.13
ITAVO	S 23:28:42.21W 46:24:03.52
GR034	S 23:23:31.48W 46:27:23.11
GR042	S 23:25:34.16W 46:31:07.62
RW10L	S 23:26:02.59W 46:28:57.06

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
FROP	FINAL APPROACH ROLLOUT POINT
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT



<b>MISSED APPROACH SEGMENT</b>																
<b>Track</b>	<b>Bank Angle(°)</b>		<b>TWC (KT)</b>		<b>IAS (KT)</b>		<b>D<sub>MASRNP</sub> (NM)</b>		<b>TrD (NM)</b>		<b>Gradient (%)</b>		<b>RNP (NM)</b>		<b>TP Altitude (FT)</b>	
	Used /	STD	Used /	STD	Used /	STD	Used /	STD	Used /	STD	Used /	STD	Used /	STD	Used /	STD
<b>ALL PARAMETERS ARE ACCORDING TO ICAO DOCUMENTS</b>																

<b>COD</b>	<b>Meaning</b>
STD	Value according to ICAO Documents
TWC	Tail Wind Component
IAS	Indicated Air Speed
D <sub>frop</sub>	Distance FROP-THEL
FROP	Final Roll-Out Point
TrD	Track Distance (Needed to comply turns)
TP Altitude	Turning Point Altitude
THEL	Threshold elevation
D <sub>MASRNP</sub>	Maximum distance of RNP navigation accuracy (requirement less than 1.0 NM in the missed approach)