



## CODING TABLE

IAC VOR Y RWY 24					SÃO LUÍS / Marechal Cunha Machado,INTL (SBSL)							SBSL_IAC_00N		30 DEC 21	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	BUTAK	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	SLI	ARVOS	AF	N/A	L	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
10	APCH	N/A	N/A	UDORI	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	SLI	ARVOS	AF	N/A	R	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
10	FINAL	N/A	N/A	ARVOS	IF	N/A	N/A	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	SLI	KOTIP	CF	244.95° Mag / 224.04° True	N/A	N/A	R1530	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	N/A	SLI	SLI02*	CF	244.95° Mag / 224.04° True	N/A	N/A	@193	N/A	N/A	4.20	-3.00	FTP	N/A
10	MA	N/A	SLI	N/A	CA	244.95° Mag / 224.04° True	N/A	N/A	+1300	220	-	N/A	N/A	N/A	N/A
20	MA	N/A	N/A	N/A	VI	59.92° Mag / 39.00° True	L	N/A	+4000	220	-	N/A	N/A	OTHER	N/A
30	MA	N/A	SLI	BUTAK	CF	104.94° Mag / 84.03° True	R	N/A	+4000	220	-	N/A	N/A	MAHF	N/A
40	MA	N/A	SLI	BUTAK	HM	284.94° Mag / 264.03° True	L	N/A	+4000	N/A	N/A	1.00 min	N/A	MAHF	N/A

\*Fictitious point only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
SLI	S 02:35:21.27W 44:14:23.89
BUTAK	S 02:34:18.52W 44:04:27.70
ARVOS	S 02:28:07.87W 44:07:27.22
KOTIP	S 02:31:44.60W 44:10:55.57
SLI02	S 02:34:46.65W 44:13:50.60
UDORI	S 02:25:21.67W 44:15:26.23

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT