



## CODING TABLE

IAC ILS Y or LOC Y RWY 02C					PIRASSUNUNGA / Campo Fontenelle, MIL (SBYS)							SBYS_IAC_00F		21 MAR 24	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	PIR	IF	N/A	N/A	N/A	+5000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	PIR	PIR	FC	211.23° Mag / 189.39° True	N/A	N/A	+4000	N/A	N/A	8.00	N/A	OTHER	N/A
30	APCH	N/A	PIR	EDLUR	CF	21.63° Mag / 359.79° True	L	N/A	R3610	N/A	N/A	N/A	N/A	FAF	N/A
10	FINAL	N/A	N/A	EDLUR	IF	N/A	N/A	N/A	R3610	N/A	N/A	N/A	N/A	FAF	N/A
20	FINAL	N/A	IYS	RW02C	CF	21.63° Mag / 359.79° True	N/A	N/A	@2018	N/A	N/A	5.00	-3.00	LTP	N/A
10	MA	N/A	N/A	N/A	VA	21.64° Mag / 359.80° True	N/A	N/A	+4000	N/A	N/A	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	PIR	DF	N/A	L	N/A	+5000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	PIR	PIR	HM	211.23° Mag / 189.39° True	R	N/A	+5000	N/A	N/A	1.00 min	N/A	MAHF	N/A

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR PIR	S 21:59:04.42W 47:20:40.21
EDLUR	S 22:04:39.70W 47:20:27.06
RW02C	S 21:59:38.65W 47:20:28.16

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT