



CODING TABLE

ILS Y RWY 16L					NATAL / Augusto Severo, MIL (SBNT)							SBNT_IAC_00J		15 JUL 21	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	NT362	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	RNAV 1 OR RNP 1
20	APCH	N	N/A	NT364	TF	162.19° Mag / 140.93° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 OR RNP 1
10	APCH	N/A	N/A	NT361	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	RNAV 1 OR RNP 1
20	APCH	N	N/A	NT364	TF	232.15° Mag / 210.91° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 OR RNP 1
10	APCH	N/A	N/A	NT363	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	RNAV 1 OR RNP 1
20	APCH	N	N/A	NT364	TF	92.22° Mag / 70.91° True	N/A	N/A	+2500	N/A	N/A	6.00	N/A	IF	RNAV 1 OR RNP 1
10	FINAL	N/A	N/A	NT364	IF	N/A	N/A	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	INT	NT366	CF	162.24° Mag / 140.94° True	N/A	N/A	R1800	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	N/A	INT	RW16L	CF	162.24° Mag / 140.94° True	N/A	N/A	@199	N/A	N/A	5.00	-3.00	LTP	N/A
10	MA	Y	N/A	NT367	TF	162.21° Mag / 140.91° True	N/A	N/A	+4000	N/A	N/A	11.40	N/A	MAHF	RNAV 1 OR RNP 1
20	MA	Y	N/A	NT367	HM	342.24° Mag / 320.91° True	R	N/A	+4000	N/A	N/A	N/A	N/A	MAHF	RNAV 1 OR RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
INT	S 05:55:17.40W 35:14:08.40
NT367	S 06:03:00.20W 35:07:52.70
NT362	S 05:41:37.70W 35:25:12.80
NT364	S 05:46:18.50W 35:21:25.20
NT361	S 05:41:08.20W 35:18:19.70
NT363	S 05:48:16.80W 35:27:06.50
NT366	S 05:50:12.50W 35:18:15.50
RW16L	S 05:54:06.65W 35:15:05.75

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT