



CODING TABLE

SID RNAV EVTIK 1A RWY 08					PASSO FUNDO / Lauro Kurtz (SBPF)							SBPF_SID_001		20 MAY 21	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	Y	N/A	EVTIK	CF	85.63° Mag 68.43° True	N/A	N/A	N/A	N/A	N/A	3.00	N/A	OTHER	RNP 1 or RNAV 1
10	EAGLE	Y	N/A	EVTIK	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	EAGLE	N	N/A	PF014	TF	177.98° Mag 160.82° True	R	N/A	N/A	N/A	N/A	20.41	N/A	OTHER	RNP 1 or RNAV 1
30	EAGLE	N	N/A	EAGLE	TF	171.94° Mag 154.81° True	L	N/A	N/A	N/A	N/A	43.47	N/A	OTHER	RNP 1 or RNAV 1
10	KIMUV	Y	N/A	EVTIK	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	KIMUV	N	N/A	KIMUV	TF	89.04° Mag 70.53° True	R	N/A	N/A	N/A	N/A	100.56	N/A	OTHER	RNP 1 or RNAV 1
10	MADBO	Y	N/A	EVTIK	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	MADBO	N	N/A	MADBO	TF	328.26° Mag 311.31° True	L	N/A	N/A	N/A	N/A	47.97	N/A	OTHER	RNP 1 or RNAV 1
10	SMA	Y	N/A	EVTIK	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	SMA	N	N/A	PF014	TF	177.98° Mag 160.82° True	R	N/A	N/A	N/A	N/A	20.41	N/A	OTHER	RNP 1 or RNAV 1
30	SMA	N	N/A	SMA	TF	245.82° Mag 230.22° True	R	N/A	N/A	N/A	N/A	108.11	N/A	OTHER	RNP 1 or RNAV 1

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
08	S 28:14:28.12 W 52:19:10.84	2380.15

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
MADBO	S 27:41:42.20W 52:56:48.80
PF014	S 28:32:42.05W 52:08:25.96
EAGLE	S 29:12:10.20W 51:47:25.80
KIMUV	S 27:40:26.94W 50:28:41.16
EVTIK	S 28:13:21.82W 52:16:01.30
SMA	S 29:42:36.24W 53:42:47.22

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE