



## CODING TABLE

IAC VOR Y RWY 12					NATAL / Campo Augusto Severo, MIL (SBNT)							SBNT_IAC_00N		21 MAR 24	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	NTL	EDROS	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	NTL	ETINA	AF	N/A	L	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
10	APCH	N/A	NTL	DAKOK	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	NTL	ETINA	AF	N/A	R	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
10	FINAL	N/A	NTL	ETINA	IF	N/A	N/A	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	NTL	ISIRI	CF	115.71° Mag 95.00° True	N/A	N/A	R1810	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	N/A	NTL	NTL18*	CF	115.71° Mag 95.00° True	N/A	N/A	R917	N/A	N/A	2.80	-3.00	SDF	N/A
40	FINAL	N/A	NTL	NTL06*	CF	115.71° Mag 95.00° True	N/A	N/A	@216	N/A	N/A	2.20	-3.00	FTP	N/A
10	MA	N/A	NTL	N/A	VD	115.71° Mag 95.00° True	N/A	N/A	N/A	N/A	N/A	10.43	N/A	OTHER	N/A
20	MA	N/A	NTL	DAKOK	AF	N/A	R	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	NTL	DAKOK	HM	357.68° Mag 336.87° True	R	N/A	+3000	N/A	N/A	1.00 min	N/A	MAHF	N/A

\*Fictitious point: Only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
EDROS	S 05:48:52.46W 35:23:44.23
DAKOK	S 06:04:07.65W 35:10:48.70
ETINA	S 05:53:35.15W 35:25:20.13
ISIRI	S 05:54:01.50W 35:20:20.24
NTL18	S 05:54:16.23W 35:17:32.30
NTL06	S 05:54:27.80W 35:15:20.34

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT