



CODING TABLE

SID RNAV KEXOX 2A RWY 28					SALVADOR / Deputado Luís Eduardo Magalhães, INTL (SBSV)							SBSV_SID_02L		12 AUG 21	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	Y	N/A	SV373	CF	281.92° Mag 258.44° True	N/A	N/A	+1100	N/A	N/A	3.00	N/A	N/A	RNAV or RNP 1
20	RWY	N	N/A	KEXOX	DF	N/A	R	B3000	B5000	N/A	N/A	N/A	N/A	N/A	RNAV or RNP 1
10	ARURU	N	N/A	KEXOX	IF	N/A	N/A	B3000	B5000	N/A	N/A	N/A	N/A	N/A	RNAV or RNP 1
20	ARURU	N	N/A	ARURU	TF	64.48° Mag 41.19° True	N/A	N/A	N/A	N/A	N/A	64.83	N/A	N/A	RNAV or RNP 1
10	AZOTE	N	N/A	KEXOX	IF	N/A	N/A	B3000	B5000	N/A	N/A	N/A	N/A	N/A	RNAV or RNP 1
20	AZOTE	N	N/A	AZOTE	TF	54.87° Mag 31.61° True	N/A	N/A	N/A	N/A	N/A	64.80	N/A	N/A	RNAV or RNP 1
10	XOBOB	N	N/A	KEXOX	IF	N/A	N/A	B3000	B5000	N/A	N/A	N/A	N/A	N/A	RNAV or RNP 1
20	XOBOB	N	N/A	XOBOB	TF	34.76° Mag 11.62° True	N/A	N/A	N/A	N/A	N/A	86.51	N/A	N/A	RNAV or RNP 1
10	ADOLF	N	N/A	KEXOX	IF	N/A	N/A	B3000	B5000	N/A	N/A	N/A	N/A	N/A	RNAV or RNP 1
20	ADOLF	N	N/A	ADOLF	TF	27.15° Mag 3.92° True	N/A	N/A	N/A	N/A	N/A	59.71	N/A	N/A	RNAV or RNP 1
10	NENIM	N	N/A	KEXOX	IF	N/A	N/A	B3000	B5000	N/A	N/A	N/A	N/A	N/A	RNAV or RNP 1
20	NENIM	N	N/A	SV037	TF	22.60° Mag 359.28° True	N/A	N/A	N/A	N/A	N/A	37.72	N/A	N/A	RNAV or RNP 1
30	NENIM	N	N/A	SV012	TF	336.71° Mag 313.43° True	L	-18000	N/A	N/A	N/A	10.00	N/A	N/A	RNAV or RNP 1
40	NENIM	N	N/A	NENIM	TF	336.68° Mag 313.60 True	N/A	N/A	N/A	N/A	N/A	68.31	N/A	N/A	RNAV or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
SV373	S 12:55:16.87W 38:23:10.51
KEXOX	S 12:45:26.12W 38:25:12.23
SV037	S 12:07:32.78W 38:25:41.08
SV012	S 12:00:38.53W 38:33:05.88
ARURU	S 11:56:30.40W 37:41:32.20
AZOTE	S 11:50:02.40W 37:50:27.00
XOBOB	S 11:20:19.81W 38:07:22.81
ADOLF	S 11:45:36.00W 38:21:01.80
NENIM	S 11:13:24.00W 39:23:34.00

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
28	S 12:54:40.64 W 38:20:09.92	30

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT