



CODING TABLE

SID RNAV KOVGO 1A - TOKOV 1A				MARICÁ / Maricá (SBMI)								SBMI_SID_00B		15 JUL 21	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	RWY	Y	N/A	MI011	IF	N/A	N/A	N/A	+600	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	RWY	N	N/A	MI007	TF	163.27° Mag / 140.17° True	N/A	N/A	-1500	N/A	N/A	2.67	N/A	OTHER	RNP 1 or RNAV 1
10	KOVGO	N/A	N/A	MI007	IF	N/A	N/A	N/A	-1500	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	KOVGO	N	N/A	KOVGO	TF	253.66° Mag / 230.76° True	N/A	N/A	N/A	N/A	N/A	32.94	N/A	OTHER	RNP 1 or RNAV 1
10	TOKOV	N/A	N/A	MI007	IF	N/A	N/A	N/A	-1500	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	TOKOV	N	N/A	TOKOV	TF	98.25° Mag / 75.13° True	N/A	N/A	+2500	N/A	N/A	4.23	N/A	OTHER	RNP 1 or RNAV 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
MI011	S 22:55:31.58W 42:50:27.63
MI007	S 22:57:35.00W 42:48:36.52
KOVGO	S 23:18:31.63W 43:16:15.01
TOKOV	S 22:56:29.68W 42:44:10.70

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
27	S 22:55:15.10W 42:50:02.06	4.00

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT