



CODING TABLE

IAC VOR RWY 12					FERNANDO DE NORONHA / Fernando de Noronha (SBN)							SBN_IAC_00F		23 JAN 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	FNR	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	FNR	FNR	FC	337.07° Mag 316.53° True	L	N/A	+2500	N/A	N/A	8.00	N/A	OTHER	N/A
30	APCH	N/A	FNR	BOKOV	CF	125.40° Mag 104.85° True	L	N/A	+2500	N/A	N/A	N/A	N/A	FAF	N/A
10	FINAL	N/A	FNR	BOKOV	IF	N/A	N/A	N/A	+2500	N/A	N/A	N/A	N/A	FAF	N/A
20	FINAL	N/A	FNR	FNR11*	CF	125.38° Mag 104.84° True	N/A	N/A	+847	N/A	N/A	5.10	-3.04	MAPT	N/A
10	MA	N/A	FNR	N/A	CA	125.39° Mag 104.85° True	N/A	N/A	+3000	250	-	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	FNR	DF	N/A	L	N/A	+4000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	FNR	FNR	HM	337.07° Mag 316.53° True	L	N/A	+4000	N/A	N/A	1.00 min	N/A	MAHF	N/A

* Fictitious point only for coding purpose.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR FNR	S 03:51:24.28W 32:25:47.78
BOKOV	S 03:49:30.00W 32:32:38.40
FNR11	S 03:50:52.10W 32:27:43.54

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT