

[illegible]

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
REC	S 08:08:11.69W 34:55:38.28
AKTOP	S 08:02:03.60W 34:57:12.80
ISADO	S 07:26:03.60W 34:30:45.60
AMBET	S 07:45:34.20W 34:26:44.40
JPS	S 07:08:25.80W 34:57:09.00
SAFUC	S 06:54:10.80W 35:06:19.80

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
18	S 08:08:22.92 W 34:55:07.57	31.56 ft MSL