



CODING TABLE

SID RNAV UDUSU 2A					GUARUJÁ / Santos, MIL (SBST)							SBST_SID_00N		20 MAR 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	DADAM	Y	N/A	UDUSU	IF	N/A	N/A	N/A	+700	N/A	N/A	N/A	N/A	IDF	RNAV 1 <i>or</i> RNP1
20	DADAM	N	N/A	ST014	TF	138.48° Mag 116.46° True	N/A	N/A	N/A	N/A	N/A	4.81	N/A	OTHER	RNAV 1 <i>or</i> RNP1
30	DADAM	N	N/A	ST016	TF	70.04° Mag 48.00° True	N/A	N/A	+3000	N/A	N/A	4.72	N/A	OTHER	RNAV 1 <i>or</i> RNP1
40	DADAM	N	N/A	SIGIL	TF	8.37° Mag 346.72° True	N/A	N/A	+5000	N/A	N/A	6.40	N/A	OTHER	RNAV 1 <i>or</i> RNP1
50	DADAM	N	N/A	DADAM	TF	303.47° Mag 281.50° True	N/A	N/A	@7000	N/A	N/A	14.50	N/A	OTHER	RNAV 1 <i>or</i> RNP1
10	IRAJA	Y	N/A	UDUSU	IF	N/A	N/A	N/A	+700	N/A	N/A	N/A	N/A	IDF	RNAV 1 <i>or</i> RNP1
20	IRAJA	N	N/A	ST018	TF	240.04° Mag 218.09° True	N/A	N/A	N/A	N/A	N/A	6.30	N/A	OTHER	RNAV 1 <i>or</i> RNP1
30	IRAJA	N	N/A	ST019	TF	308.62° Mag 286.70° True	N/A	N/A	+5000	N/A	N/A	6.60	N/A	OTHER	RNAV 1 <i>or</i> RNP1
40	IRAJA	N	N/A	IRAJA	TF	344.31° Mag 322.41° True	N/A	N/A	@7000	N/A	N/A	7.76	N/A	OTHER	RNAV 1 <i>or</i> RNP1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
UDUSU	S 23:56:39.20W 46:17:22.03
ST014	S 23:58:48.01W 46:12:40.63
ST016	S 23:55:37.94W 46:08:50.86
SIGIL	S 23:49:23.40W 46:10:27.00
DADAM	S 23:46:30.24W 46:25:56.56
ST018	S 24:01:36.73W 46:21:35.60
ST019	S 23:59:42.61W 46:28:31.57
IRAJA	S 23:53:32.37W 46:33:41.86

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT